

# aspire®

## Breeze NXT

### User Manual

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the legal age, pregnant or breast feeding women and those experiencing general ill health.



#### Contents

- 1\* Breeze NXT Battery Unit
- 1\* Breeze NXT Pod
- 2\* 0.8Ω Mesh Coils
- 1\* Micro USB Cable
- 1\* Warranty Card
- 1\* User Manual

#### Specifications

- Pod capacity: 5.4ml
- Built-in battery capacity: 1000mAh
- Dimensions: 35\*96\*20.5mm
- Fire button
- Airflow adjustable on the side
- Coil resistance: 0.8Ω (mesh coil)
- Coil material: Kanthal AF
- Replaceable coils
- Easy side fill
- Bypass output mode

*Please note: The Breeze NXT coils are made specifically for the Breeze NXT and are NOT interchangeable with the Breeze or Breeze 2*

#### Coil Installation

1. Pull and remove the pod from the main body;
2. Invert the pod and pull out the used coil;
3. Put a new coil into the chamber;
4. Re-insert the pod into the power unit.



#### Tank Filling

1. Lift the silicone seal on the side of the pod;
2. Place the tip of filling bottle into the pod filling hole;
3. Squeeze the filling bottle to add your preferred e-liquid into the pod system;
4. Replace the silicone seal firmly.



- When installing a new coil, let the pod stand for 5 minutes after filling so the cotton can be saturated with e-liquid before use.
- Do not let the pod become completely empty. Refill the pod to avoid dry burning or damage to the coil.

#### Instructions

- Pressing the fire button five times quickly will turn the device on or off. The LED light will flash white 3 times to indicate on or off.
- When the Breeze NXT is in use, the light will indicate your device's current charge. When its current charge is above 3.8 volts, the LED light will be green. When the charge is between 3.5 and 3.8 volts, the light will be blue. When the charge drops below 3.5 volts, the light will then turn red to remind you that it is time to charge your Breeze NXT.

#### Protective Features

- Automatic Cutoff: The preset continuous fire time is 8 seconds, after 8 seconds of continuous firing, the LED light will flash purple 10 times and the device will stop firing.
- Short Circuit Protection: When the device detects a short, it will stop firing, and the LED light will flash purple 3 times.
- Low Voltage Protection: When the battery level drops below 3.2V, the device will not function and the LED light will flash red 15 times to remind you to charge your Breeze NXT.
- Overcharge Protection: When the Breeze NXT is fully charged, it will stop charging to prevent overcharging of your battery.
- Over Heat Protection: When the temperature of the chip is above 75 °C/167 °F, the LED light will be yellow for 3 seconds and the Breeze NXT will cut off.

#### Charging Instructions

- Charge via the Micro USB port. Maximum charge current can reach up to 1A, we recommend to use the output 5V/1A wall adaptor.
- When the USB cable is attached, the LED light will flash red 3 times. While charging the LED will indicate the Breeze NXT's current charge status: 3.5 volts or less = red light; 3.5 to 3.8 volts = blue light; 3.8 volts and above = green light. When the Breeze NXT is fully charged, the LED will flash green 20 times then remain off. When unplug the USB cable, the LED will flash green 3 times.

#### IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

#### NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

#### WARNINGS AND PRECAUTIONS

**Nicotine containing e-liquids are not recommended for:**

- Non-smokers
- Young people under the legal age;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a pheochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
  - Theophylline (to treat breathing problems)
  - Ropinirole (to treat restless legs)
  - Clozapine (to treat schizophrenia)

#### POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)
- Headache
- Coughing
- Irritation of the mouth or throat
- Dizziness
- Stomach discomfort
- Hiccups
- Nasal congestion
- Vomiting (being sick)
- Heart palpitations
- Abnormal heart rate

If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

#### Safety note:

To avoid misfiring always ensure you either lock or switch off your device when it is not in use. Especially when carrying your device in your pocket, bag or purse.

To learn more about your products and how to use, please visit: [www.aspirecig.com](http://www.aspirecig.com)

**Shenzhen Eigate Technology Co., Ltd.**

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China  
Tel: +86-755-81499783 Email: [service@aspirecig.com](mailto:service@aspirecig.com)

Manufactured By Eigate

MADE IN CHINA

