aspire

CYBER X

DEEP PRAIRIE

EN

DISCLAIMER
Please read this user manual before use. Failure to follow the instructions in this manual may result in fire, electric shock, or other injury or damage to the vape, personal injury, death, or property damage.

The manufacturer assumes no responsibility for any damage caused by mishandling that is beyond normal usage defined in this manual.

RECOMMENDED SETUP
We recommend the exclusive use of Aspire original charger, battery, and accessories. Aspire shall not be responsible for any charger, battery, user's of third parties, batteries, components, and/or accessories not specifically produced for this device may lead to malfunction and damage to the product and to the cancellation of the warranty.

HANDLING AND USAGE SAFETY
To reduce the risk of fire, shock, or damage to your vape device keep the product and its accessories away from overheated or excessively humid conditions (-10°C / 50°C).

Your device can be damaged if dropped, burned, punctured, crushed, or if it comes in contact with liquid. If you suspect damage to your device or its battery, discontinue use of your device, as it may cause overheating or injury.

To avoid inhaling always ensure your vape is switch off your device when not in use. Do not place vape/pod/cartridge/ device in your pocket, bag or purse.

In the cases of burnt or abnormal deformation of one of the components of the device or its accessories, stop using it immediately and contact Customer Service.

COIL MAINTENANCE SAFETY
In order not to damage the coil or burn the cotton do not inhale an empty pod, use the pod/tank stand for 5 minutes after filling the cotton can be saturated with e-liquid before use.

REPLACEABLE BATTERIES SAFETY
Do not use non-rechargeable batteries. Do not use damaged rechargeable batteries. Do not leave batteries in the device when not in the battery. Trim the charger when fully recharged. Do not use your vape device while charging.

PRODUCT DISPOSAL SAFETY
Do not discard this product and/or batteries in the environment, and only dispose of them in the appropriate or dedicated collection/recycling disposal.

HEALTH WARNING SAFETY
Do not use the product if you are pregnant, breastfeeding, generally ill, or suffer from respiratory and/or cardiovascular system diseases.

If you experience any side effects/discomfort with the product, if the effect(s) continue after you stop using, consult a healthcare professional immediately.

Components View:

Package Contents:
* 1 Cyber X Device
* 1 Pod Kit (2 ml / 0.8 Ω)
* 1 Coil Pod (2 ml / 0.8 Ω)
* 1 Type-C Cable
* 1 Drip Tip Adapter
* 1 Lanyard

Specifications:
Dimensions: 75 x 17.5 x 25 mm
Capacity: 2 ml / 5 ml
Coil: Coil 1 (0.6 Ω) Mesh coil, non-replaceable
Battery Capacity: Built in 1000 mAh
Charging: Type-C, 2A
Output: 3 V–5 V constant output
Activation: Draw to fire button
Mode: 8 button activated
Mode: 4 button activated (button activated)

Pod Filling:
1. Pull to remove the pod.
2. Fill the e-liquid through the top of the pod.
3. Fill e-liquid into the pod by pressing the top fill slot.
4. Plug back in the mouthpiece.
5. Wait 5 minutes before use.

Instructions:

Device Condition	Status of Indicators & Details
Current Present	Flash white 1 time
Fully Charged (Continuously press the button 3 times within 2 s)	Flash white 3 times
Battery level > 51 (50-80%)	On red
Battery level > 3 (5-51%)	On blue
Battery level < 3 (<5%)	On green
Lockout	Flash red 3 times

Note: Device enters a locked state when its current exceeds 3 A. Lockout will occur in the protection mode if the current exceeds the set value or if the current is too low.

How to Adjust the Activation Modes:

Step	Action	Indicator Status	Mode Status
Step 1	Switch the device to the power mode (press the fire button 5 times within 2 seconds)	Mode indicator flashes red 3 times	Current mode
Step 2	Within the working 3s, press the fire button 3 times to switch the mode	Up and down indicator flashes red 3 times	Switch to the next mode
Step 3	Waiting for 3 seconds	Current mode indicator flashes 3 times	Mode confirmed

Remember to clean the condensation between the atomizer and the device.



Protection Features:

Over-Time Protection (OE)	The LED indicator will flash red and the device will shut off. The device will lock out.
Short Circuit Protection	The LED indicator will flash red. The device will shut down.
Low Voltage Protection	The LED indicator will flash red.
Overheat Protection	Once the temperature is fully charged, the LED indicator will flash green 30 times and the device will stop charging.
Over Voltage Protection	The LED indicator will stay yellow for 3 seconds and then turn off. The device will shut down.
Over Voltage Protection	When charging is abnormal, the LED indicator will flash red and the charger will stop.

Charging:

Maximum charge current	2A
Intermediate charge voltage	4.2V
Charge cut-off voltage	Fully charged
Overheat protection threshold	Unplug the Type-C cable
LED indicator flashing green 3 times	Unplug the Type-C cable

IMPORTANT INFORMATION ABOUT USING NICOTINE-CONTAINING E-LIQUIDS
Before using nicotine-containing e-liquid the user should read the following information carefully.

1. NICOTINE CONTAINING E-LIQUID:
Nicotine is a highly addictive substance. It should be noted that nicotine is not the only substance in e-liquids that causes harm, since it includes also other substances. Nicotine causes different effects to consumers especially in relation to children.
Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

2. NICOTINE WARNINGS AND PRECAUTIONS
* Nicotine is highly addictive and toxic.
* Do not consume.
* Do not use if you are under the legal age.
* Pregnant or breast-feeding women: as nicotine is addictive and toxic, the placenta and breast-feeding women are advised not to consume.
* Nicotine may impair general ill-health, such as heart problems, if you have cardiovascular or circulatory problems, long term heart disease, or difficulty breathing due to bronchitis, emphysema, or asthma.
* Those who have an unusual form of gastric or bowel problem, such as ulcer, Crohn's disease, or diarrhea that can affect high blood pressure.
* Those who have diabetes, nicotine may affect your blood sugar levels.
* Those taking the following medication: Insulin, Adrenergic agonists (Salbutamol), Adrenergic antagonists (Beta-blockers), Xanthines (Theophylline), Clozapine (To treat schizophrenia).

3. POSSIBLE SIDE EFFECTS
Nicotine is highly addictive, and the user may find it hard to stop. The product has not much you may experience one or more of the following effects:
* Nausea
* Nausea (Feeling sick)
* Headache
* Irritation of the mouth or throat
* Dizziness
* Stomach discomfort
* Sneezing
* Nasal congestion

4. MOUTHPIECE CONTAINING E-LIQUID:
Nicotine is highly addictive and toxic. It should be noted that nicotine is not the only substance in e-liquids that causes harm, since it includes also other substances. Nicotine causes different effects to consumers.
Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

5. NICOTINE WARNINGS AND PRECAUTIONS
* Nicotine is highly addictive and toxic.
* Do not consume.
* Do not use if you are under the legal age.
* Pregnant or breast-feeding women: as nicotine is addictive and toxic the placenta and breast-feeding women are advised not to consume.
* Nicotine may impair general ill-health, such as heart problems, if you have cardiovascular or circulatory problems, long term heart disease, or difficulty breathing due to bronchitis, emphysema, or asthma.
* Those who have an unusual form of gastric or bowel problem, such as ulcer, Crohn's disease, or diarrhea that can affect high blood pressure.
* If you have diabetes, nicotine may affect your blood sugar levels.
* Those taking the following medication: Insulin, Adrenergic agonists (Salbutamol), Adrenergic antagonists (Beta-blockers), Xanthines (Theophylline), Clozapine (To treat schizophrenia).

6. POSSIBLE SIDE EFFECTS
Nicotine is highly addictive, and the user may find it hard to stop. The product has not much you may experience one or more of the following effects:
* Nausea
* Nausea (Feeling sick)
* Headache
* Irritation of the mouth or throat
* Dizziness
* Stomach discomfort
* Sneezing
* Nasal congestion

7. NICOTINE CONTAINING E-LIQUID:
Nicotine is highly addictive and toxic. It should be noted that nicotine is not the only substance in e-liquids that causes harm, since it includes also other substances. Nicotine causes different effects to consumers.
Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

8. NICOTINE WARNINGS AND PRECAUTIONS
* Nicotine is highly addictive and toxic.
* Do not consume.
* Do not use if you are under the legal age.
* Pregnant or breast-feeding women: as nicotine is addictive and toxic the placenta and breast-feeding women are advised not to consume.
* Nicotine may impair general ill-health, such as heart problems, if you have cardiovascular or circulatory problems, long term heart disease, or difficulty breathing due to bronchitis, emphysema, or asthma.
* Those who have an unusual form of gastric or bowel problem, such as ulcer, Crohn's disease, or diarrhea that can affect high blood pressure.
* If you have diabetes, nicotine may affect your blood sugar levels.
* Those taking the following medication: Insulin, Adrenergic agonists (Salbutamol), Adrenergic antagonists (Beta-blockers), Xanthines (Theophylline), Clozapine (To treat schizophrenia).

9. POSSIBLE SIDE EFFECTS
Nicotine is highly addictive, and the user may find it hard to stop. The product has not much you may experience one or more of the following effects:
* Nausea
* Nausea (Feeling sick)
* Headache
* Irritation of the mouth or throat
* Dizziness
* Stomach discomfort
* Sneezing
* Nasal congestion

ES

DESCARGO DE RESPONSABILIDAD
Por favor, lea este manual de usuario antes de usar el producto. Si no sigue las instrucciones de este manual puede provocar un incendio, una descarga eléctrica u otras lesiones o daños a la vape, daños personales, la muerte o daños materiales.

El fabricante no asume ninguna responsabilidad por los daños causados por un mal manejo que vaya más allá del uso normal definido en este manual.

CONFIGURACIÓN RECOMENDADA
Recomendamos el uso exclusivo de cargador original, la batería, los componentes y los accesorios originales de Aspire indicados en la etiqueta. Aspire no se hará cargo de cualquier cargador, batería, componentes y/o accesorios no fabricados específicamente para este dispositivo puede provocar un mal funcionamiento, daños en el producto y la anulación de la garantía.

SEGURIDAD DE MANIPULACIÓN Y USO
Para reducir el riesgo de incendio, descarga o daños en su dispositivo de vapeo, mantenga el producto y sus accesorios lejos de condiciones de calor/humedad excesivamente húmedas (-10°C / 50°C).

Su dispositivo puede dañarse si se cae, se quema, se pincha, se aplasta o si entra en contacto con algún líquido. Si sospecha que su dispositivo o su batería está dañado, deje de usarlo, ya que puede provocar un sobrecalentamiento o lesiones.

Para evitar que se produzcan fallos de ennoxado, asegurese siempre de bloquear o apagar el dispositivo cuando no lo esté. Por otro lado, especialmente cuando lo lleve en el bolsillo, el bolso o la cartera.

En caso de quemadura o deformación anormal de uno de los componentes del aparato o de sus accesorios, deje de utilizarlo inmediatamente y póngase en contacto con el Servicio de Atención al Cliente.

SEGURIDAD EN EL MANTENIMIENTO DE LAS BOBINAS
Para no dañar la bobina o quemar el algodón no inhale una cápsula vacía. Deje reposar la cápsula/tanque durante 5 minutos después de rellenar el algodón o el algodón puede estar saturado antes de usarlo.

BATERÍAS REEMPLAZABLES SEGURAS
No utilice pilas no recargables. No utilice pilas dañadas/con un/ha sido aplastada. No deje las baterías en el dispositivo cuando no esté cargando. Recorte el cargador cuando esté completamente cargado. No utilice su dispositivo de vapeo mientras se está cargando.

SEGURIDAD EN LA ELIMINACIÓN DEL PRODUCTO
No deseche este producto y la batería en el medio ambiente, y sólo los corrija/recicle en los contenedores o puntos de recogida/eliminación especiales.

AVISO DE SALUD SEGURIDAD
No utilice el producto si está embarazada, en periodo de lactancia, si está generalmente enfermo/a o si padece trastornos del sistema respiratorio y/o cardiovascular.

Si experimenta efectos secundarios/molestias, deje de usar el producto, si los efectos continúan después de dejar de usarlo, consulte a un profesional de la salud inmediatamente.

Contenido:
* 1 Dispositivo Cyber X
* 1 Pod Kit (2 ml / 0.8 Ω)
* 1 Pod Kit (2 ml / 0.8 Ω)
* 1 Cable Type-C de 2A
* 1 Adaptador de Drip
* 1 Cordón

Vistas de componentes:

Recuerde limpiar la condensación producida entre el cartucho y el dispositivo.

Características técnicas:
Dimensiones: 75 x17.5 x 25 mm
Capacidad: 2 ml / 5 ml
Parámetros de la bobina: Cabeza de malla de 1.0Ω (0.8Ω)
Capacidad de batería incorporada: 1000 mAh
Carga: Tipo-C, 2A
Salida constante de 3.0 V
3 modos de activación: Modo 8 = cabada automática
Modo 8 = activación con el botón de cabada
Modo 4B = cabada automática + activación con el botón de cabada

Relleno del pod:
1. Tire del pod para quitarlo.
2. Descargue el líquido por la parte superior.
3. Llene el líquido en la ranura prensionada de la ranura de llenado.
4. Vuelva a enchufar la boquilla.
5. Espere 5 minutos antes de usarlo.

Instrucciones:

Dispositivo	Estado de los/ indicadores y detalles
Dispositivo Desconectado/ en espera	Parpadeo 1 vez
Dispositivo cargado (presione continuamente el botón de cebado 3 veces)	Parpadeo 3 veces
Nivel de batería > 51% (50-80%)	En rojo
Nivel de batería > 3 (5-51%)	En azul
Nivel de batería < 3 (<5%)	En verde
Cierre	El dispositivo entra en un estado bloqueado cuando su corriente supera los 3 A. Se producirá un cierre en el modo de protección si la corriente supera el valor establecido o si la corriente es demasiado baja.

Cambiar el modo de activación:

Paso	Acción	Estado del indicador	Estado del modo
Paso 1	Cambiar el dispositivo al modo de potencia (presione el botón de disparo 5 veces en 2 segundos)	El indicador de modo parpadea en rojo 3 veces	Modo actual
Paso 2	Dentro de los 3 segundos de espera, presione el botón de disparo 3 veces para cambiar el modo	El indicador de encendido y apagado parpadea en rojo 3 veces	Cambiar al siguiente modo
Paso 3	Esperando 3 segundos	El indicador de modo parpadea 3 veces	Modo confirmado

Características de protección:

Protección contra el tiempo de vapeo (OE)	La luz LED parpadeará en rojo y apagará 3 veces y el dispositivo se apagará
Protección contra cortocircuitos	La luz LED parpadeará en rojo 3 veces.
Protección de baja voltaje	La luz LED parpadeará en rojo 1 vez.
Protección contra sobrecalentamiento	El dispositivo dejará de cargarse
Protección contra sobrecargas	La luz LED parpadeará en verde 30 veces y el dispositivo se apagará
Protección contra sobretensión	El dispositivo permanecerá en estado de espera durante 3 segundos y luego se apagará.
Protección contra sobrecarga	Cuando la carga sea anormal, el indicador LED de cargará en rojo y el dispositivo se apagará.

Carga:

Corriente de carga máxima	2A
Voltaje de carga recomendado	4.2V
Voltaje de corte de carga completa	Totalmente cargado
Umbral de temperatura de sobrecalentamiento	Desenchufe el cable USB
La luz LED parpadeará verde 3 veces	Desenchufe el cable USB

INFORMACIÓN IMPORTANTE SOBRE LOS E-LÍQUIDOS QUE CONTIENEN NICOTINA
Antes de utilizar un e-líquido que contiene nicotina, el usuario debe leer cuidadosamente la siguiente información.

1. E-LÍQUIDO CON NICOTINA:
Si se utiliza un e-líquido que contenga nicotina, debe tenerse en cuenta que la nicotina, que no una sustancia altamente adictiva y por lo tanto, no es necesario que la nicotina sea la única sustancia que provoca daños, ya que también incluye otras sustancias.
La nicotina provoca efectos diferentes en los consumidores, especialmente en los niños.
No lo use si es alérgico a la nicotina o a cualquiera de los otros ingredientes contenidos en el e-líquido (consulte la etiqueta del fabricante para obtener todos los detalles).

2. ADVERTENCIAS Y PRECAUCIONES SOBRE LA NICOTINA
* La nicotina es muy adictiva y tóxica.
* No la consuma.
* (Jóvenes menores de edad)
* A menor edad (jóvenes menores de edad) la nicotina, ya que se sabe que la nicotina es adictiva y tóxica, y las embarazadas y las madres lactantes.
* La nicotina puede perjudicar una enfermedad general, como enfermedades del corazón, úlceras de estómago y duodeno, enfermedades cardiovasculares, enfermedades del corazón a largo plazo, o dificultades para respirar debido a bronquitis, enfisema o asma.
* Quienes tienen una glándula o hombre especifico o tienen un desarrollo/cáncer/ulcera de estómago/ulcera duodenal/ulcera de colon/ulcera de recto/ulcera de boca/ulcera de garganta/ulcera de esófago/ulcera de pulmón/ulcera de ojo/ulcera de piel/ulcera de vejiga/ulcera de riñón/ulcera de hígado/ulcera de bazo/ulcera de pancreas/ulcera de intestino delgado/ulcera de intestino grueso